




SKU # 1000 050 222  
Model # TY029-1414

## USE AND CARE GUIDE

### Burlap Owl Family



#### THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this Burlap Owl Family. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

#### Guarantee

#### What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

#### What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

1-877-527-0313


HOMEACCENTSHOLIDAY.COM

## Pre-Assembly

### PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

### PACKAGE CONTENTS



Package Contents/Parts List		
Part	Description	Quantity
A	Head of Big Owl	1
B	Body Halves of Big Owl	2
C	Wings of Big Owl	2
D	Head of Small Owl	1
E	Body Halves of Small Owl	2
F	Wings of Baby Owl	2

Package Contents/Parts List		
Part	Description	Quantity
G	Decorative Collar	2
H	Ground Stakes	8
I	Spare Fuse	2
J	Spare Bulb	7
K	Plastic Tie	15

## Assembly

### Assembling the Owls




FIG. 1

Step 1. Align the two Body Halves of Big Owl (B) with each other and fasten together with the Plastic Ties (K). FIG. 1

Step 2. Stand the Body section in an upright position . Place the Decorative Collar (G) on top of the Body then Insert the rod of Head of Big Owl (A) into the matching holes on top of the Body of the Big Owl and fasten together with the Plastic Ties. FIG.1

Step 3. Repeat Steps 1 & 2 above for the Small Owl. FIG. 1




FIG. 2

Step 1. Insert the metal rods attached to each Wings of Big Owl (C) into the matching holes on the Big Owl Body and fasten with the Plastic Ties. FIG. 2

Step 2.Repeat Step 1 above for fastening wings to Small Owl. FIG 2

Step 3. Secure the Owls to the ground with the Ground Stakes (H). FIG.2

## Pre-Operation

**CAUTION:** Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

**CAUTION:** The lighting string on this product is rated at 43.2 Watts (0.36Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

## Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

## FOR INDOOR AND OUTDOOR USE